



LIST OF SPARES

Item No.	Description	Pack	R2218 R2260 R2316	R2219 R2282	R2220	R2221	R2283 R2315	R2279M	R2286	R2388	R2385	R2458	R2436
1	Motor Retainers	1 + 1	X8995	X8995	X8995	X8995	X8995	X8995	X8995	X8995	X8995	X8995	X8995
2	Motor Assembly	1	X4026	X4026	X4026	X4026	X4026	X4026	X4026	X4026	X4026	X4026	X4026
3	Cylinder Block	1	X8996	X8996	X8996	X8996	X8996	X8996	X8996	X8996	X8996	X8996	X8996
4	Valve Gear Set	set	X8997	X9029	X8997	X8997	X8997	X9095	X8997	X8997	X8997	X8997	X8997
5	Gear Set	set	X8849	X8849	X8849	X8849	X8849	X8849	X8849	X8849	X8849	X8849	X8849
6	Loco Wheel / Axle Set	set	X8998	X8998	X8998	X8998	X9047	X9047	X9124	X8998	X8998	X8998	X8998
7	Speedometer Assembly	set	X8856	X8856	X8856	N / A	N / A	N / A	N / A	N / A	X8856	X8856	N / A
8	Loco Chassis Bottom	1	X8999	X8999	X8999	X8999	X8999	X8999	X9130	X8999	X8999	X8999	X8999
9	Bogie Assembly	1	X4018	X4018	X4018	X4018	X4018	X4018	X9126	X4018/1	X4018/1	X4018/1	X4018/1
10	Couplings	pack	X8302	X8302	X8302	X8302	X8302	X8302	X8302	X9289	X9289	X9289	X9289
11	Pony Truck Assembly	1	X9000	X9000	X9000	X9000	X9000	X9000	X9127	X9000	X9000	X9000	X9000
12	Draw Bar Assembly	1	X8846	X8846	X8846	X8846	X8846	X8846	X8846	X8846	X8846	X8846	X8846
13	Tender Chassis Assembly	1	X9002	X9002	X9028	X9002	X9002	X9002	X9131	X9028	X9002	X9002	X9002
14	Tender Wheel Set	set	X8853	X8853	X8853	X8853	X8853	X8853	X9125	X8853	X8853	X8853	X8853
15	Tender Chassis Bottom with Screws	1 + 3	X9027	X9027	X9027	X9027	X9027	X9027	X9027	X9027	X9027	X9027	X9027
Not Illustrated	Accessory Pack	pack	X4268	X4268	X4268	X4268	X4268	X4268	X4857	X4268	X5110	X4268A	X4268A
*	Small Parts Pack	pack	X8855	X8855	X8855	X8855	X8855	X8855	X8855	X8855	X8855	X8855	X8855